



SP 10 Sound Projector





Remove mounting bracket from loudspeaker.


3



COLOR	SP 10
Blue	СОМ
Red	10 W
Yellow	5 W
Green	2.5 W

2

(4)



Fix mounting bracket on the flat surface.

Place loudspeaker in mounting bracket and set rotation angle.

Please pay attention: Mount the loudspeaker on the reliable base only.

Connect speaker to signal line via block terminal.