

WIRELESS MICROPHONES

iLive 2 UHF Body Pack Wireless Transmitters

iLive 2 body pack wireless microphone transmitters.

iLIVE 2BP body pack transmitter

iLive 2 BP wireless transmitter with built-in LCD display and battery level meter. Channel frequency and battery level are displayed on LCD screen. Body pack wireless transmitter should be used with iLive2 receivers



Technical Specifications	iLIVE 2BP
Carrier frequency range	606 MHz - 621 MHz
Modulation	FM
Channels	32
Audio frequency response	45 Hz - 18 kHz
S/N ratio	> 105 dB
Antenna	1/4 wave antenna
Transmitter's power	3 mW
Working range	60 m (Note: actual range depends on RF signal absorption, reflection and interference)
Polar pattern	Cardiod
Dimensions	110 mm x 64 mm x 25 mm
Weight	76 g
Material	Plastic